



Principle maintenance rules L20-22 B-E 2012

AT THE END OF THE WORK









- 1. Close the water tap
- 2. Lift the brushes and squeegee
- 3. Turn off the machine pressing the **ON/OFF** switch
- 4. Check the wear of the brushes or discs (to be replaced before the pad holder is being damaged)





Do not vacuum flammable products such as: alcohol, spirits, trichloroethylene, solvents, etc.

DAILY MAINTENANCE









- 1. Cleaning the recovery tank
 - Empty the tank using the hose, turning the knob and then removing the cap
- 2. Cleaning the recovery tank

Open the recovery tank lid and clean the tank with a water jet. Close the cap of the discharge hose and replace it on the machine

3. Cleaning the squeegee

Clean the squeegee with a jet of water and clean the lower part by hand

4. Cleaning the solution tank filters

With the solution tank **empty:**

- 1. Unscrew the lid
- 2. Remove and clean the cartridge
- 3. Open the tap
- 4. Rinse the tank with a jet of water.
- 5. Reassemble everything, repeating the abovementioned operations in the reverse order

WEEKLY MAINTENANCE



1. Rear squeegee rubber

(if worn, change the dryer side; replace after all sides are worn)

2.-3.

Cleaning the suction motor filter

Extract the suction motor filter and clean it with a jet of water





You should always wear protective gloves to avoid the risk of serious injury to hands

ADJUSTING THE SQUEEGEE

Follow the manufacturer's instructions